

REAP WEAPONRIES

Building Buffered (Standard)

How- To build a Scy Bullpar using a buffered upper receiver you will need to choose a shortened stock system to reduce the buffer tube length. This will get you a manageable length of pull in the bullpup platform. Listed below are a few options we recommend when choosing make sure to use a system that supports the caliber you are building for. There are other options to choose from other manufacturers that we do not carry.

Why-

- Vast parts options
- Easily interchangeable parts
- Familiarity
- Appearance
- Common availability

Upper receiver requirements-

- M Lok or Key Mod
- Rail outer diameter under 1.75"
- Slim barrel nut

Stock options-

- The Stave
- Law Tactical Aric (RAP with sickle or Pistol Plate)
- Other shortened stock systems to reduce length of pull

Conversion Uppers-

- 22lr drop in bolts
- Bolt action upper receivers (requires XPS TS-1 stock)

