

REAP WEAPONRIES

Building Bufferless

How- To build a Scy Bullpar using a bufferless upper receiver purchase one of the listed upper receivers that have been proven to fit. Use the supplied picatinny rail adapter or purchase one you prefer. Attach the adapter to your Mil Spec lower receiver, followed by the Scy kit, the upper and a stock of your choosing from the list below.

Why-

- Shorter length of pull
- Forward charging
- Easy out of the box set up
- Weight distribution
- Caliber options

Upper receiver options-

- Brownells BRN-180
- PSA Jakl Gen 1
- Foxtrot Mike FM15
- CMMG Dissent
- Faxon ARAK 21
- Tink Perun x16

Stock options-

- Sickle
- Sickle poly (Flat or curved profile)
- Xps Ts-1 (BRN- 180 only)
- Rail Cover

Conversion Uppers-

- 22lr drop in bolts
- Bolt action upper receivers (requires XPS TS-1 stock)

